





TOP - ROTARY LIMIT SWITCH

Reference	Code	Description
1	VI100005	Screw M5x2 ISO 7045
2	VI100011	Screw M3x9 ISO 7045 -4.8
3	PA01AA01	Yankee HF
4	FCN20001 FCN20002 FCN20003 FCN40001 FCN40002 FCN40003 FCN40004 FCN40005 FCN40006	Cams D + D Cams D + E Cams E + E Cams F + F + C + B Cams D + D + D + D Cams D + D + E + E Cams E + E + E + E Cams E + E + E + A Cams D + D + A + A See reference chart below for cam specification
5	PRVI0180PE	Screw 4x16 UNI 8112 - Z/SW
6	PRSL9497PI	Bush n.7
7	PRSL6703PI	Central gear wheel Z 100
8	PRTO0091PE	Wheel support pin mm 35.5
9	PRTO0092PE	Wheel support pin mm 42
10	PRCB0015PE	Bearing 21x12x5
11	PRGU0013PE	Tightening ring
12	PRTO3018PE	Flange support
13	PRVI0223PE	Screw M5x16 UNI 5931-8.8
14	PRTR1300PE	Flange
15	ALB1R00001	Standard shaft
16	PRRN1113PE	Elastic ring UNI 7435 for shaft
17	PRFU3500PE PRFU3500P6	Base 20 π Base 60 π
18	PRGO0026PE	Tappo di tenuta
19	PRPS1075PE	Cable clamp M20x1.5
20	PRTO0090PE	Wheel support pin mm 28
21	PRSL9491PI	Bush n.1
22	PRTR0021PE	Tegolino quadro per collegamento a terra
23	PRVI0158PE	Screw M4x8 UNI8112
24	PRSL9492PI	Bush n.2
25	PRSL6598PI PRSL6599PI PRSL6600PI PRSL6601PI PRSL6602PI PRSL6603PI PRSL6604PI PRSL6605PI PRSL6606PI PRSL6607PI PRSL6608PI PRSL6609PI PRSL6611PI PRSL6612PI PRSL6613PI PRSL6614PI PRSL6615PI PRSL6616PI PRSL6617PI PRSL6618PI PRSL6619PI PRSL6620PI PRSL6621PI PRSL6622PI PRSL6623PI PRSL6624PI	Lateral gear wheel Z 35 Lateral gear wheel Z 37 Lateral gear wheel Z 36 Lateral gear wheel Z 38 Lateral gear wheel Z 40 Lateral gear wheel Z 42 Lateral gear wheel Z 44 Lateral gear wheel Z 46 Lateral gear wheel Z 48 Lateral gear wheel Z 50 Lateral gear wheel Z 52 Lateral gear wheel Z 54 Lateral gear wheel Z 56 Lateral gear wheel Z 58 Lateral gear wheel Z 60 Lateral gear wheel Z 62 Lateral gear wheel Z 64 Lateral gear wheel Z 66 Lateral gear wheel Z 68 Lateral gear wheel Z 70 Lateral gear wheel Z 72 Lateral gear wheel Z 74 Lateral gear wheel Z 76 Lateral gear wheel Z 78 Lateral gear wheel Z 80 Lateral gear wheel Z 82

Reference	Code	Description
25	PRSL6625PI PRSL6626PI PRSL6627PI PRSL6628PI PRSL6629PI PRSL6630PI PRSL6631PI PRSL6632PI PRSL6633PI PRSL6634PI PRSL6635PI PRSL6636PI PRSL6637PI PRSL6638PI PRSL6639PI	Lateral gear wheel Z 84 Lateral gear wheel Z 86 Lateral gear wheel Z 88 Lateral gear wheel Z 90 Lateral gear wheel Z 92 Lateral gear wheel Z 94 Lateral gear wheel Z 96 Lateral gear wheel Z 98 Lateral gear wheel Z 100 Lateral gear wheel Z 102 Lateral gear wheel Z 104 Lateral gear wheel Z 106 Lateral gear wheel Z 108 Lateral gear wheel Z 107 Lateral gear wheel Z 109
26	PRSL9496PI	Bush n.6
27	PRSL9273UL	Plate
28	PA020000	Potentiometer support
29	PRVV9020PE PRVV9021PE PRVV9025PE PRVV9026PE PRVV9030PE PRVV9031PE PRVV9032PE PRVV9035PE PRVV9037PE	Potentiometer Megatron 4.7 kΩ Potentiometer Sfernice 5 kΩ ±10% Potentiometer Megatron 10 kΩ Potentiometer Sfernice 10 kΩ ±10% Potentiometer MCB 10 kΩ fermo mecc. Potentiometer MCB 10 kΩ Potentiometer Novoteknik 2 kΩ Potentiometer Megatron 2.2 kΩ Potentiometer Eurofarad 2.2 kΩ ±20%
30	PA030000	Encoder support
31	PRVV6500PE PRVV6502PE	Encoder 36 pulses/rev. Encoder 150 pulses/rev.
32	PRGU0045PE	Tightening rubber
33	PRFU3550L2 PRFU3550L6	Cover 20 π with rubber (32) Cover 60 π with rubber (32)
34	PRSL0911PI PRSL0912PI PRSL0913PI PRSL0914PI PRSL0915PI PRSL0916PI PRSL0917PI PRSL0918PI PRSL0944PI	Pinion gear M10 Z12 Pinion gear M12 Z10 Pinion gear M14 Z10 Pinion gear M16 Z10 Pinion gear M20 Z8 Pinion gear M5 Z12 Pinion gear M6 Z11 Pinion gear M8 Z12 Pinion gear M12 Z12
35	PRSL0919PI	Male coupling with pin
36	PRSL0920PI	Female coupling with pin
37	PRSL0981PI	Coupling

Cam reference chart

(degrees correspond to mechanical angle)



The data and the products illustrated in this brochure may be modified without notice. Under no circumstances can their description have a contractual value.

Offshore Version: codes available on request.

